

REMOVE 1" x 1 1/2" BLOCK OUT

COMPLETELY WET REGLET AREA AND LET DRY  
JUST SO MOISTURE SHEEN DISAPPEARS.

APPLY XYPEX CONCENTRATE SLURRY COAT  
(5-6 SF/LB) TO REGLET AREA AND LET SET  
UNTIL IT IS DRY TO TOUCH, BUT STILL MOIST  
GREEN

MIX XYPEX 80/20 MIX FOR DRY-PAC 6:1 (6 PARTS  
XYPEX 80/20 MIX WITH 1 PART WATER) BY VOLUME  
TO A LUMPY DRY CONSISTENCY.

HAMMER PACK TIGHTLY INTO REGLET AREA WITH A  
HARDWOOD 1x4 AND SMALL SLEDGE HAMMER

AFTER INITIAL SET OF THE DRY-PAC MATERIAL  
APPLY XYPEX GAMMA CURE TO THE DRY-PAC  
AREA AT A RATE OF 850 SF PER MIXED GALLON  
(MIX 3 PARTS WATER TO 1 PART XYPEX GAMMA CURE)

(XYPEX 80/20 MIX: THOROUGHLY DRYMIX  
4 PARTS XYPEX PATCH N' PLUG WITH 1 PART  
XYPEX CONCENTRATE)

INSTALL PEEL & STICK WATERSTOP  
(GREEN STREAK SWELL STOP OR EQUAL  
MIN. 1" x 1 1/2"), ON PRIMED SUBSTRATE.

#5  
REBAR(TYP)

CONCRETE SLAB  
OR FOUNDATION WALL

#5 REBAR  
(TYP)

NOTE:  
DO NOT ROUND  
OR TROWEL CORNERS

